

Manual Supplement

Manual Title:	15B+/17B+/18B+ Users	Supplement Issue:	1
Part Number:	4372130	Issue Date:	10/14
Print Date:	February 2014	Page Count:	1
Revision/Date:			

This supplement contains information necessary to ensure the accuracy of the above manual.

Change #1, 465

On page 13, following the **Measure Frequency and Duty Cycle (17B+/18B+ Only)** section add:

Hazardous voltage alert LED (17B+ only)

HAZARDOUS VOLTAGE ALERT LED (17B+ only)

To alert you to the presence of a potentially hazardous voltage, when the Product detects a voltage ≥ 30 V or a voltage overload (OL), the Hazardous voltage alert LED below keypad "Hz/Duty cycle" will turn on (17B+ only).

Note:

The hazardous voltage alert LED will turn on at Frequency/Duty cycle test when the Product is in voltage functions (volts AC/DC and millivolts).

On page 18, under **Specifications** replace the **Relative Humidity** section and add:

Operating Humidity.....Non-condensing (<10°C); ≤ 90 % RH at 10 °C to 30 °C; ≤ 75 % RH at 30 °C to 40 °C

Operating Humidity, 40 MΩ Range..... ≤ 80 % RH at 10 °C to 30 °C; ≤ 70 % RH at 30 °C to 40 °C